

BM20結線図

BM20N

	①	③	④	⑤	⑥
off	Lo	ST	BAT	E	IG
I 入	●	●	●	●	●
II 始動	●	●	●	●	●

35100-768-S01

コントロールボックス

- 1 BAT

2 CL SW

3 UP LS

4

5 CL ON LS

6 CL OFF LS

7 SEAT SW

8 PEDAL SW

9 KEY SW

10 BAT

11 R SW

12 L SW

13 DWN SW

14 UP SW

15 RESET

16 MODE

17 GND

18 BAT

19 IG OUT

20

21 SW LAMP

22 SEL OUT

23 R OUT

24 L OUT

25 GND

26 UP OUT

27 UP OUT

28 FLOAT

29 FLOAT

30 CL OFF

31 CL OFF

32 CL ON

33 CL ON

34 GND
- 0.85Y

0.5V

0.50

0.5GB

0.85YW

0.85GO

0.5YR

0.85L

0.85Y

0.5PB

0.5VL

0.5WR

0.50L

0.85B

0.85Y

0.5RW

0.85YB

0.85GO

0.85GR

0.85LR

0.85B

0.85LY

0.85LY

0.85LG

0.85LG

0.85P

0.85P

0.85Sb

0.85Sb

0.85B

